


SMART SHADES OPERATING MANUAL



CONTENTS

- 1. Q&A 1
- 2. Remote Control Parameters 2-3
- 3. Motor Parameters 4-5
- 4. Connect To App 6-10
- 5. Remote Control Settings 11-24
- 6. Group Settings 25-26
- 7. Time And Timer Settings 27-33

Q&A

Q1: What is jogs?

A: The shade (motor) go up then go down to calculate Jogs once.

Q2: Why does the shade only move a little when I press the up/down button?

A: The limit have been lost or switched to dot move mode. Please refer to Page 12 to reset the limit. If fail, please refer to page 16.


Q3: How should I adjust the height?

A: Please refer to Page 17–18.


Q4: I only have two shades and I don't need so many channels. Can I delete the channels?

A: Yes, please refer to Page 24.


REMOTE CONTROL PARAMETERS




REMOVE THE PLASTIC SHEET





FRONT OF REMOTE



BACK OF REMOTE



BLE BATTERY MOTOR



USB Charger




Solar Panel
(Optional)



Power bank
(Not included)


WI-FI WIRED MOTOR




MOTOR CONNECT TO APP




APP control directly, please download the APP Smart Life.
Please turn on the Bluetooth of your mobile phone when you pair or control blinds.



Press and hold the reset button for 6s






Shade jogs X2



Blue light keeps flashing after you release it.

OPEN SMART LIFE AND ADD DEVICE



Smart Gateway



Alexa

or




Google Home

For more functions like timing, long-range control, or Alexa/Google Home control, you need to buy a Gateway if it is Battery Motor.
For details, please contact customer service.




Please refer to hub instruction

CONTROL INTERFACE




SETTING INTERFACE



CONNECT TO ALEXA/ GOOGLE

Use the Smart Life to pair your Smart Blinds with Amazon Alexa and Google Home Assistant and enjoy a full hands-free experience.

1. After you succeed in connecting blinds with Smart Life, enter the “Me” page to find the “Third-Party Voice Services” area.



2. Pair Smart Life with Smart Device Account.

a. Pair with Alexa:

Press Alexa button and sign in with your Amazon account.
(Please use the same Amazon account with your Alexa)

b. Pair with Google Assistant:

Press Google button and sign in with your Google account.
(Please use the same Google account with your Google Assistant)


PAIR WITH MOTOR

1




Press “<” or “>”, choose channel

2




Press and hold Reset Button for 3s




Shade jogs X1

3



Press “P” within 10s




Shade jogs X2



- 1.Please press the P button multiple times if motor no response.
- 2.Please ensure the remote control is not in group mode.Unable to pair in group mode.

SET THE LIMIT

1




The Upper Limits point

Move to the Upper Limits you want


One press	→	Dot Move
Hold for 2S	→	Continuous Move

2




Press and hold “↑” & “♥” for 2s

»



Shade jogs X2


3




The Lower Limits point

Move to the Lower Limits you want

4



Press and hold “↓” & “♥” for 2s





Shade jogs X2




PERCENT MOVE

1



Press “” for 3 times

2




Press “” or “”, increase/decrease percent

3


Wait for three seconds, the shade will go to the percent.




SET FAVORITE POSITION



Please move the shade to your favorite position (except Upper&Lower limits)




Press and hold “□” & “♥” for 2s




Shade jogs X2




DELETE THE FAVORITE POSITION



Shade is at Fav. position



Press and hold “□” & “♥” for 2s




Shade jogs X1




CHANGE UP/DOWN DIRECTION

If limits are set


1




Press "P"





Press "↑"





Press "↓"
















Shade jogs X1

Shade jogs X1

Shade jogs X1



If limits are not set




Press and hold "P" & "Heart" for 2s




CONTINUOUS MOVE ⇔ DOT MOVE

1




Press " P "

>>




Shade jogs X1

2




Press " □ "

>>




Shade jogs X1

3



Press " □ "

>>




Shade jogs X1




ADJUST THE UPPER LIMIT

1




Press and hold “↑” & “♥” for 6s



Shade jogs X1


2




Move to the new Upper Limits you want

- One press ➡ Dot Move
- Hold for 2S ➡ Continuous Move

3



Press and hold “↑” & “♥” for 2s




Shade jogs X2




ADJUST THE LOWER LIMIT

1




Press and hold “↓” & “♥” for 6s




Shade jogs X1

2


Move to the new Lower Limits you want



3



Press and hold “↓” & “♥” for 2s




Shade jogs X2




ADJUST RUNNING SPEED

1




Press " P "




Shade jogs X1

2




Press " □ "




Shade jogs X1

3




Press " ↑ "




Shade jogs X1

Speed increase



Press " ↓ "



Shade jogs X1


Speed decrease




REMOVE/PAIR SHADE WITH REMOTE B BY REMOTE A

 Remote A must be paired with the Shade.

1




Press “ P ” on
Remote A




Shade jogs X1



2




Press “ P ” on
Remote A




Shade jogs X1



3



Press “ P ” on
Remote B




Shade jogs X1




REMOVE A CHANNEL

1




Press and hold Reset Button for 2s




Shade jogs X1

2



Press " P "





Shade jogs X1





DELETE THE UPPER&LOWER LIMIT



1




2




3



RESET THE MOTOR



Press and hold Reset Button for 10S



Shade jogs x4





ADJUSTING THE NUMBER OF CHANNELS

1




Press “ < ” or “ > ”, switch to channel 1

2





Press and hold “ ♥ ” & “ > ” for 3s

3



Press “ < ” or “ > ” to increase/decrease channels

4



Press “ □ ”





ADJUSTING THE NUMBER OF GROUPS

1




Press “ < ” or “ > ”, switch to channel 0

2





Press and hold “ ♥ ” & “ > ” for 3s

3



Press “ < ” or “ > ” to increase/decrease groups

4



Press “ □ ”



SET GROUP CONTROL

1




Press “<” or “>”, choose group

2



Press and hold “♥” & “>” for 3s

3



Press “<” or “>”, choose the channel you want, and press “♥” to place/remove channels



Steady-Lit
Flickering



Group included this channel
Group **NOT** included this channel

4




Press “□”



TURN ON/OFF TIMER FUNCTION


1



Press“ T ”

Timer ON

2




Press“ T ”

Timer OFF




SET LOCAL TIME

1




Under Timer off mode

2




Press “ T ” for 3s




Hour Flicker

3





Press “↑” or “↓” to adjust time and week

4




Press “<” or “>” to switch hour, minute, and week

5



Press and hold “T” for 3s to complete set

6



Press “♥” to start count



SET TIMER CONTROL


1.Enter program mode: press“♥” any time to exit timer setting, data cleaned.

1




Under Timer on mode

2



Program 1

3




Press “↑” or “↓” to choose program


Note: 1. Press Up&Stop, LCD shown CL00, means current data cleared
2. Press Down&Stop, LCD shown CP01, means first data set copied to current set

2.Set the timer

1




Press “>” to next



Channel setting

2



Press “↑” or “↓” to choose the channel you want ,and press “□” to place/remove channels




Steady-Lit
Flickering




Included this channel
NOT included this channel

3




Press “>” to next



Weekday setting

4





Press “↑” or “↓” to choose the day you want ,and press “□” to place/remove days



Steady-Lit → Included this day
Flickering → NOT included this day



5



Press “>” to next

Set **up** hour and minute

6




Press “>” to next


Set **up** percentage



7




Press “>” to next




Set **down** hour and minute

8




Press “>” to next




Set **down** percentage

9



Press “T” for 3s



SMART SHADES OPERATING MANUAL

Version: 3.2 Date: August, 15, 2023